

THE EPISCOPAL CHURCH OF BETHESDA-BY-THE-SEA, PALM BEACH

Austin Organs, Inc. h Op. 2777 h 1999/2000

Chancel: 67 ranks h Gallery: 42 ranks

Chancel GREAT

16 Violone
8 Diapason
8 Violone
8 Bourdon
4 Octave
4 Nachthorn
2 Fifteenth
IV Fourniture (2½')
III Cymbal (1') †
16 Double Trumpet †
8 Trumpet †
4 Clarion †
8 Cor Séraphique (SOLO)
Tremolo
Chant Organ
Unison Off
Tower Bells
MIDI

† enclosed with Chancel Choir

Gallery GREAT (enclosed)

16 Bourdon
8 Principal
8 Bourdon
8 Bois Céleste II
4 Octave
4 Rohrflute
2 Principal
II Sequialtera (T.C.)
IV Mixture (1½')
16 Kontra Trompete
8 Trompete
8 Cromorne
8 Cor Séraphique (SOLO)
Tremolo
Chimes
Zymbelstern
Unison Off
MIDI

Chancel SWELL (enclosed)

16 Lieblich Gedeckt
8 Diapason
8 Flûte à Cheminée
8 Viola
8 Viola Céleste
8 Flauto Dolce
8 Flute Céleste (T.C.)
4 Principal
4 Flûte Octavante
4 Viola
4 Viola Céleste
2 Flautino
III Plein Jeu (2')
III Cymbal (1')
16 Waldhorn
8 Cornopean
8 French Trumpet
8 Oboe
8 Vox Humana
(in a box)
4 Clarion
8 Cor Séraphique (SOLO)
Tremolo
Vox Humana Tremolo
MIDI

Swell 16
Unison Off
Swell 4
Chant Organ

Gallery SWELL (enclosed)

16 Contra Gamba
8 Geigen Principal
8 Flûte Oûverte
8 Viole de Gambe
8 Voix Céleste
8 Nitsua
8 Nitsua Céleste
4 Principal
4 Flûte Harmonique
4 Viole de Gambe
4 Voix Céleste
2 Blockflute
1½ Larigot
III Mixture (2')
16 Bassoon
8 Trompette
8 Hautbois
8 Vox Humana
(in a box)
4 Clairon
8 Cor Séraphique (SOLO)
Tremolo
Vox Humana Tremolo
MIDI

Swell 16
Unison Off
Swell 4

Chancel CHOIR (enclosed)

16 Dulciana
8 Geigen Diapason
8 Hohlflute
8 Dulciana
8 Unda Maris (T.C.)
4 Octave Geigen
4 Koppel Flute
2½ Nasard
2 Piccolo
1½ Tierce
1½ Larigot
16 Clarinet
8 Clarinet
8 Cor Séraphique (SOLO)
Tremolo
Harp
Celesta
MIDI
Choir 16
Unison Off
Choir 4
Chant Organ

Chancel SOLO (enclosed)

8 Gamba
8 Gamba Céleste
8 Harmonic Flute
4 Orchestral Flute
8 English Horn
8 French Horn
8 Tuba Mirabilis
4 Tuba Clarion
16 Cor Séraphique (T.C.)
8 Cor Séraphique
4 Cor Séraphique
MIDI
Tremolo
Chant Organ
Harp
Celesta
Tower Bells
Chimes (Gallery)
Solo 16
Unison Off
Solo 4

Chancel CHANT ORGAN

8 Gedeckt
4 Suave Flute
2 Spitzflute

Chancel PEDAL

32 Open Wood
32 Untersatz
16 Principal
16 Bourdon
16 Violone (GREAT)
16 Lieblich Gedeckt (SWELL)
16 Dulciana (CHOIR)
8 Octave Bass
8 Gedeckt
8 Flûte à Cheminée (SWELL)
4 Choral Bass
III Mixture (2')
64 Ophicleide
32 Grand Cornet VI
32 Ophicleide
16 Trombone
16 Double Trumpet (GREAT)
16 Waldhorn (SWELL)
8 Trumpet
4 Clarion
4 Clarinet (CHOIR)
8 Cor Séraphique (SOLO)
Tower Bells
Chant Organ
MIDI

Gallery PEDAL

32 Contra Violone
16 Open Wood
16 Principal
16 Subbass
16 Bourdon (GREAT)
16 Gamba (SWELL)
8 Octave
8 Bourdon (GREAT)
4 Choral Bass
III Mixture (2')
32 Contra Posaune
16 Posaune
16 Kontra Trompete (GREAT)
16 Bassoon (SWELL)
8 Trompete
4 Clarion
4 Cromorne (GREAT)
8 Cor Séraphique (SOLO)
Chimes
MIDI

REVERSIBLES

Open Wood 32
 Contra Bourdon 32
 Ophicleide 32
 Untersatz 32
 Contra Posaune 32
 Ophicleide 64
 Chancel Swell/Pedal
 Gallery Swell/Pedal
 Chancel Great/Pedal
 Gallery Great/Pedal
 Solo/Pedal
 Choir/Pedal
 Chant on Pedal
 Chancel Swell/Great
 Gallery Swell/Great
 Choir/Great
 Solo/Great
 All Swells to Swell
 Narthex call light
 Chancel Tutti
 Gallery Tutti
 Full Organ

COUPLERS

Chancel
 Great/Pedal 8
 Swell/Pedal 8
 Swell/Pedal 4
 Choir/Pedal 8
 Choir/Pedal 4
 Solo/Pedal 8
 Solo/Pedal 4
 Swell/Great 16
 Swell/Great 8
 Swell/Great 4
 Choir/Great 16
 Choir/Great 8
 Choir/Great 4
 Choir/Great 4
 Solo/Great 16
 Solo/Great 8
 Solo/Great 4
 Swell/Choir 16
 Swell/Choir 8
 Swell/Choir 4
 Solo/Choir 16
 Solo/Choir 8
 Solo/Choir 4
 Great/Choir 8
 Great/Solo 8
 Swell/Solo 8
 Choir/Solo 8
 Choir/Swell 8
 Solo/Swell 8

Pedal Divide

Chancel Swell/Pedal Acc
 Chancel Choir/Pedal Acc
 Gallery Swell/Pedal Acc
 Gallery Great/Pedal Acc

Selecting **PEDAL DIVIDE** prohibits Manual to Pedal coupling to bottom 12 Pedal keys; selecting any of the **ACCOMPANIMENT** couplers (Chancel or Gallery) allows selected division to couple only to bottom 12 keys; all "regular" pedal couplers work in the top 1½ octaves

Gallery

Great/Pedal 8
 Swell/Pedal 8
 Swell/Pedal 4
 Swell/Great 16
 Swell/Great 8
 Swell/Great 4
 Swell/Choir 16
 Swell/Choir 8
 Swell/Choir 4
 Great/Choir 8
 Swell/Solo 16
 Swell/Solo 8
 Swell/Solo 4
 Great/Solo 8

ACCESSORIES

Piston sequencer
 All Swells to Swell
 Great/Choir transfer
 Chancel Organ off
 Gallery Organ off
 MIDI sequencer
 80 levels of memory (individually lockable)
 Duplicate 4-manual consoles
 Transposer
 Melody Solo [couples Solo to Great on top note only]
 Pedal Pizzicato [momentarily brings on Chancel Pedal Bourdon 16']
 Auto Pedal [when playing on Great, plays pedal division on bottom note only]
 General Cancel
 Chancel Cancel
 Gallery Cancel
 Division cancellers
 Adjustable Crescendo Pedal
 Adjustable Tutti
 Recordable memory set-up
 Adjustable music rack